



Tech Info Library

LaserWriter: Upper Fuser Roller Melting

Revised: 4/7/93
Security: Everyone

LaserWriter: Upper Fuser Roller Melting

=====

Problem: Due to excessive heat from the fuser heater bulb, the upper fuser roller is damaged or partially melted.

Cause #1: The problem can be caused by a defective thermistor.

Cause #2: There could be a defective fuser thermal protector, or a dirty thermistor.

Cure: First, replace the damaged upper and lower fuser rollers, along with the cleaner felt, then go on to the steps listed below. Be sure to pay close attention to the heat of the fuser assembly to avoid damage to the new parts.

#1: Replace or clean the thermistor.

#2: Replace the fuser thermal protector.

Copyright 1987, Apple Computer, Inc

Tech Info Library Article Number:211