

Tech Info Library

DMP Self Test Problems

Revised: 11/7/88 Security: Everyone

DMP Self Test Problems

This article last reviewed: 1 November 1988

DESCRIPTION:

This table is composed of fixes for typical DMP Self Test problems.

YOU WILL NEED:

The Apple Service Level I Technical Procedures

BEFORE YOU START:

- 1. Refer to the Technical Procedures if removal/replacement or adjustment procedures are needed.
- 2. If a replacement module/part doesn't fix the problem, reinstall the original module/part.

INSTRUCTION:

- 1. Press the Form Feed switch while you turn on the DMP, the printer should print a line of characters (one character set).
- 2. Find your PROBLEM below and perform the corresponding FIX.

PROB: There is a burning odor, erratic carrier motion, or erratic platen

rotation.

FIX: Recheck for the problem after replacing each of the following parts:

- (1) CPU PC board
- (2) Carrier motor
- (3) Mechanical assembly
- (4) Transformer

PROB: The printer doesn't print a character set when Self Test is

- FIX: Perform the following steps. Retry the Self Test if a problem
 - (1) Check that the top cover is seated properly. If it isn't, close it. Then press SEL and retry self-test.
 - (2) Check if PE lamp is lit on switch panel. If it is, reload paper
 - (3) Check the connectors between the carrier and carrier motor and the

..TIL01398-DMP_Self_Test_Problems_(TA30590).pdf

CPU PC board. If any of the connectors are loose, connect them.

- (4) Replace the CPU PC board.
- (5) Replace the Carrier motor.

PROB: The printer prints a character set when Self Test is initiated but the print quality is poor.

FIX: Find your print quality problem in the tables below.

* DOTS MISSING

- (1) Make sure dot head is in place.
- (2) Make sure dot head is not clogged with dirt.
- (3) Make sure dot head connector is plugged properly in CPU board.
- (4) Check impression control lever properly set. Push it away from you to its forwardmost position if using single sheet of paper.
- (5) Replace the Dot head.
- (6) Replace the CPU PC board.

* PRINT TOO LIGHT OR VARYING INTENSITY

- (1) Check impression control lever properly set. Push it away from you to its forwardmost position if using single sheet of paper
- (2) Substitute new ribbon cartridge.
- (3) Check if ribbon wire tension is loose and adjust as necessary.
- (4) Adjust intensity pot located under the clear plastic sheet that covers the configuration switches. Locate VR2 IMPRES and adjust for optimum print density.
- (5) Replace the Ribbon cassette.
- (6) Replace the Dot head.
- (7) Replace the CPU PC board.

* HORIZONTAL SPACING PROBLEM

- (1) Check if carrier wire is strung properly or out of tension specification.
- (2) Replace the Carrier wire.
- (3) Replace the Carrier motor.
- (4) Replace the CPU PC board.
- * CHARACTERS DO NOT ALIGN VERTICALLY BETWEEN LINES
 Locate VR1 ALIGN under the clear plastic sheet that covers the
 configuration switches. Adjust for optimum vertical alignment.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:1398