

## Newton MessagePad: Hard Resets Occur After Low Power (3/94)

Revised: 3/18/94 Security: Everyone

Newton MessagePad: Hard Resets Occur After Low Power (3/94)

\_\_\_\_\_\_

Article Created: 18 March 1994

TOPIC -----

When I turn on my Newton MessagePad, I get the message "Do you want to erase data?". What is causing this to happen?

DISCUSSION -----

The message is an indication that a hard reset has occurred. A hard reset erases only the information you have stored. It does not remove Newton's programs or operating system software (including system updates).

The normal procedure for doing a hard reset is to slide down the on/off switch, hold it down as you press the Reset button in the battery compartment, and then release the on/off switch.

There are also two unusual situations that can trigger a hard reset. If the Newton MessagePad is low on power, then a power fault flag is set. Once this flag is set, if the power switch is held for an extended duration, a hard reset is triggered. If the Newton MessagePad quits and resets itself, and the power switch is held down, a hard reset is also triggered.

No changes will be made to the software or hardware to eliminate this from occurring.

Support Information Services

Copyright 1994, Apple Computer, Inc.

Tech Info Library Article Number: 14643