

Tech Info Library

TokenTalk: How To Find Burned-In Address

Revised: 6/21/91 Security: Everyone

TokenTalk: How To Find "Burned-In" Address

Article Created: March 9, 1991

Article Reviewed Only: Article Last Updated:

TOPIC -----

How can I find out what the "burned-in" address is for my TokenTalk Card?

DISCUSSION -----

Although you can find out what the "burned-in" address is using the MacDFT Config CDEV, there are times when you don't have this handy.

When holding the card, port to the right and the chip set facing you, look for the ROM card (the card on the card). Now look for the serial number of the card. It is printed on a label two chips to the left of the ROM card on the second row from the top. It is proceeded with S/N.

Once you have found this decimal number, convert it to hex. Now add the result (in hex) to 5000E0000000. This will be your address.

For example:

If your card's serial number is: 1969 (with a bunch of leading zeros)

1969 base 10 = 7B1 hex

 $5000E0000000 + 7B1 = 5000E00007B1 \le your address.$

Copyright 1991 Apple Computer, Inc.

Tech Info Library Article Number:7180