



Tech Info Library

AppleWorks: Settings and Codes for Star Dot Matrix Printer

Revised: 12/17/87
Security: Everyone

AppleWorks: Settings and Codes for Star Dot Matrix Printer

=====

This article last reviewed: 11 December 1987

Do not change the default settings of the Custom printer except -- for Platen Width, which should be changed to 13.2 inches in case the printer has a wide carriage.

Menu Item	Value	Entry
-----	-----	-----
1. Characters per inch	5	[ESC]B[CTRL-A][ESC]W[CTRL-A]^
1. Characters per inch	6	[ESC]B[CTRL-B][ESC]W[CTRL-A]^
1. Characters per inch	10	[ESC]B[CTRL-A][ESC]W[CTRL-@]^
1. Characters per inch	12	[ESC]B[CTRL-B][ESC]W[CTRL-@]^
1. Characters per inch	17	[ESC]B[CTRL-C][ESC]W[CTRL-@]^
2. Lines per inch	6	[ESC]2^
2. Lines per inch	8	[ESC]0^
3. Boldface	begin	[ESC]G^
3. Boldface	end	[ESC]H^
3. Subscript	begin	[ESC]S[CTRL-A]^
3. Subscript	end	[ESC]T^
3. Superscript	begin	[ESC]S[CTRL-@]^
3. Superscript	end	[ESC]T^
4. Underlining	begin	[ESC]-[CTRL-A]^
4. Underlining	end	[ESC]-[CTRL-@]^

Tech Info Library Article Number:58