



Tech Info Library

ImageWriter: Superscripting, Subscripting, and Underlining

Revised: 7/30/90
Security: Everyone

ImageWriter: Superscripting, Subscripting, and Underlining

=====

This article last reviewed: 21 September 1984

A set of superscripted and subscripted characters resides as an alternate font in a file on the "Imagewriter Tool Kit" diskette, which is included in the accessory kit. An option of the Tool Kit menu downloads the super/sub-scripted character font. After the download, you can invoke the alternate font with "ESC '"; "ESC \$" restores the standard (switch selected) character font. In this font, symbols generate superscripted numerals, and numbers generate subscripted numerals.

Applewriter accomplishes superscripts and subscripts on Imagewriters with serial numbers 250001 or greater. If the serial number is less, the Imagewriter must be upgraded.

NOTES:

1. The word Escape in the following instructions refers to hitting the Escape key.
2. The blanks should not be keyed in; they are there to make the strings readable.
3. The command strings take up room in the line and are counted as characters when printing takes place, even though the commands themselves are not printed.

In an Applewriter file:

1. Type in [V] Escape l [V]. This enables the optional line feed function.
2. To do a superscript:
 - a. Type: [V] Escape T 12 Escape r [J] [V]
 - b. Enter the superscript text.
 - c. Type: [V] Escape f [J] Escape T 24 [V]

3. To do a subscript:

- a. Type: [V] Escape T 12 [J] [V]
- b. Enter the subscript text.
- c. Type: [V] Escape r [J] Escape f Escape T 24 [V]

Underlining requires no printer modification. Just send "ESC X" to start underlining and "ESC Y" to stop it. Apple Writer users will probably not use this method to underline; however, if they do, note that X and Y are uppercase.

Copyright 1990 Apple Computer, Inc.

Tech Info Library Article Number:162