



Tech Info Library

Lisa: Daisy Wheel Printer Settings

Revised: 7/30/87
Security: Everyone

Lisa: Daisy Wheel Printer Settings

=====

Switch 1: 11100111
Switch 2: 10010000
Numbered 8 to 1; 1 = On, 0 = Off
Space Parity
Local
EXT/ACK Handshaking
9600 Baud
Paper out on
Duplex & Auto CR/LF off
Bi directional print on
ASCII Standard

Use a "Modem Eliminator" cable, part number 590-0029, in series with the interface cable.

Tech Info Library Article Number:419