



Tech Info Library

Lisa: Daisy Wheel Printer Error Numbers

Revised: 7/30/87
Security: Everyone

Lisa: Daisy Wheel Printer Error Numbers

=====

Error	Meaning
1199	DMP selected in Format for Printer
648	No modem eliminator cable or Preference not set properly
3056	Generic printer problem - check cables, paper, ribbon, etc.

Tech Info Library Article Number:420