

LisaGuide: Startup

Revised: 11/15/84 Security: Everyone

LisaGuide: Startup

IMPORTANT FACT: The LisaGuide diskette doesn't contain any system startup instructions, so if you try to start LisaGuide solely from the diskette, a crossed out Lisa icon and an error 10735 is displayed.

To boot LisaGuide: Startup From... the ProFile with your LisaGuide diskette in the drive.

If you're still unable to boot LisaGuide, your Office System or your LisaGuide diskette may be damaged. First, repair and reinstall the Office System startup software as described on p. D50 in the Lisa 1 Owner's Guide or p. C24 in the 2's guide; then, repair the LisaGuide diskette. If LisaGuide still doesn't boot, replace the diskette.

Good Things to Know About Lisa

Tech Info Library Article Number:470