



# Tech Info Library

## DOS: Version 3.3 and the language card

Revised: 11/20/84  
Security: Everyone

DOS: Version 3.3 and the language card

=====

At power up, DOS 3.3 looks at location \$E000, both on the motherboard and on the firmware card, to check which version of BASIC is available. If a Language card is present, DOS tries to jump into some random information on the card. This jump is prevented by a machine language routine that places a \$00 at \$E000 on the Language card during booting. This routine is stored on the DOS diskette at track 0, sector 9, starting at byte \$D3

Apple Tech Notes

Tech Info Library Article Number:565