

Lisa: Format for Printer

Revised: 10/8/84 Security: Everyone

Lisa: Format for Printer

When printer format settings are made for a document, other blank documents and stationary pads may also change their printing formats to the new settings.

This can only happen to documents or stationary pads, such as the LisaWrite stationary pad, that have never had text or data entered into them. The printer format settings of non-empty documents and stationary pads will not change unless specifically set by the Format for Printer dialog box while the document is open.

Apple Technical Communications

Tech Info Library Article Number:737