



Tech Info Library

Lisa/Macintosh XL: RS-232 and RS-422 Pinouts for Serial Port B

Revised: 7/30/87
Security: Everyone

Lisa/Macintosh XL: RS-232 and RS-422 Pinouts for Serial Port B

=====

The signals available on Serial Port B of the Lisa are shown in Figure 3-9, page 3-24 of the Lisa Hardware Manual (for RS-232) and on page 3 of Macintosh Technical Notes #10 (for RS-422). This data is combined here.

Pin No.	RS-232 Name	RS-422 Name	Notes
1	Ground	Ground	
2	Transmit data	TxD-	
3	Receive data	RxD-	
4	Request to send		
6	Data set ready	HSK/DSR	TRxCB or CTSB
7	Ground	Ground	
19	AppleTalk receive data	RxD+	
20	Data terminal ready	TxD+/DTR	Connected to DTRB

Tech Info Library Article Number:801