

Lisa 7/7: Printing Executive PS on a DWP

Revised: 3/4/85 Security: Everyone

Lisa 7/7: Printing Executive PS on a DWP

When you select to print a document on a Daisy Wheel Printer in Executive PS, the printer sometimes simply ejects a blank page. If this occurs, select Elite 12, Courier 10 or Gothic 15 instead; your DWP will then print properly.

Apple Technical Communications

Tech Info Library Article Number:887