



Tech Info Library

IIc Monitors PROBLEM/CURE: Intermittent Flashing Screen

Revised: 1/30/92
Security: Everyone

IIc Monitors PROBLEM/CURE: Intermittent Flashing Screen

=====

This article last reviewed: 29 April 1988

PROBLEM DESCRIPTION: Video display intermittently appears and disappears.

CAUSE: RCA connectors on either end of the video cable from the monitor to the computer may not be making good contact.

CURE: Slightly crimp (squeeze with a pair of pliers) the shield part of the RCA connector on the video cable on both ends so that it makes slightly tighter fit on the monitor and the computer.
(DO NOT OVERCRIMP; it must be snug only).

If this cure does not resolve the problem, go to the Tech Procedures to obtain a General Troubleshooting procedure.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:1593