



Tech Info Library

Lisa/Macintosh XL: Configuration Table

Revised: 1/17/92
Security: Everyone

Lisa/Macintosh XL: Configuration Table

This article last reviewed: 24 February 1988

To line up the items in the table below, print it in Monaco 9.

BASIC LISA/MAC XL CONFIGURATION TABLE

Systems:->		LISA 2	MACINTOSH XL	MODIFIED
Basic		(LISA 2/5 if	(LISA 2/10)	MACINTOSH XL
Features:		connected to		(Screen Mod
(Below)		ProFile)		Kit Installed
INTERNAL		NO	YES	YES
HARD				
DISK		Notes:	Notes:	Notes:
		Runs Lisa 7/7 Office System and MacWorks	Runs Lisa 7/7 Office System and MacWorks	Runs MacWorks only
MICRODISK		YES	YES	YES
DRIVE				
		Notes:		
		Requires Lisa Lite adapter board in disk drive chamber		
BUILT-IN		YES	NO	NO
PARALLEL				
PORT		Notes:	Notes:	Notes:
		Can connect Pro- File or other parallel device to motherboard	Must install parallel inter- face card in expansion cham- ber to access parallel device	Must install parallel interface card in expansion chamber to access par- allel device
		Can install Mac	When using Lisa	Internal hard

		Works and/or Lisa7/7/ Office on a connected ProFile	7/7 Office System internal hard disk can access ProFile and other parallel devices	disk runs MacWorks only: cannot access ProFile, but can access parallel prin- ter if driver is installed
			When using Mac- Works, internal hard disk cannot access ProFile, but can access parallel prin- ter if driver is installed	
=====	=====	=====	=====	=====
TWO BUILT-IN SERIAL PORTS	Present:	YES	YES	YES
	Notes:	Has three DB-25 connectors in back	Only two DB-25 connectors in back	Only two DB-25 connectors in back
=====	=====	=====	=====	=====
8-AMP POWER SUPPLY - rated at 1.2 amps AC	Present:	YES	NO	NO
=====	=====	=====	=====	=====
10-AMP POWER SUPPLY - rated at 1.8 amps AC	Present:	NO	YES	YES
=====	=====	=====	=====	=====

Interpreting the Basic Lisa2/Macintosh XL Configuration Table

The top row (across) lists the system names for three basic configurations of the Lisa2/Macintosh XL. The first column (down) lists the names of basic hardware components. The YES or NO listed under each system indicates whether the hardware component is or is not a required part of that system. The "Notes" provide important information about software compatibility and hardware configuration for each system.

Copyright 1988, Apple Computer, Inc.

Tech Info Library Article Number:1827