



Tech Info Library

LaserWriter: Laser Power Adjustment

Revised: 7/28/89
Security: Everyone

LaserWriter: Laser Power Adjustment

=====

This article last reviewed: 10 November 1988

When the laser is replaced in a first-generation LaserWriter (LaserWriter and LaserWriter Plus), the laser power must be adjusted by a pot on the DC controller board.

In the LaserWriter II, there is no pot on the DC controller board. Power adjustment is not needed during laser replacement.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:2930