



Tech Info Library

ImageWriter LQ & A4: Workaround To Paper Length Problem

Revised: 8/1/88
Security: Everyone

ImageWriter LQ & A4: Workaround To Paper Length Problem

=====

This article last reviewed: 12 July 1988

An ImageWriter LQ has a DIP switch that configures the form length of continuous paper at 11 or 12 inches. A4 is 11.69 inches. When printing from the driver with A4 and continuous paper selected, the perforation position changes -- for obvious reasons.

Changing the position of switch 1-4 (Page Length) makes no difference in the page length when printing from a Macintosh. The page length remains 11 inches whether switch 1-4 is in the ON or OFF position.

To correct this problem, change the position of switch 1-5 (Perforation Skip), then select A4 page length and continuous paper, and print.

Copyright 1988 Apple Computer, Inc.

Tech Info Library Article Number:3105