

## CD Remote: Controls Only the First of Multiple CD-ROM Drives

Revised: 6/16/92 Security: Everyone

CD Remote: Controls Only the First of Multiple CD-ROM Drives

\_\_\_\_\_\_

Article Created: 11 June 1990 Article Last Reviewed: 29 May 1992 Article Last Updated: 29 May 1992

TOPIC -----

How will the desk accessory "CD Remote" act if more than one CD-ROM unit is hooked to a Macintosh, and standard CD audio disks are placed in all drives?

DISCUSSION -----

If more than one Apple CD-ROM device is used on a Macintosh computer, the device with the lowest SCSI number is the unit that CD Remote will control. As an example, two CD-ROM devices are on the SCSI bus. One has a SCSI ID of 2 and the other has an SCSI ID of 5. The CD-ROM device with the SCSI ID of 2 will be the unit accessed by CD Remote. There is no way to change this.

Copyright 1990, 1992, Apple Computer, Inc.

Tech Info Library Article Number: 5762