

Tech Info Library

ImageWriter II: Troubleshooting Garbled Printing

Revised: 9/3/91 Security: Everyone

ImageWriter II: Troubleshooting Garbled Printing

Article Created: 15 July 1990

Article Last Reviewed: 30 August 1991 Article Last Updated: 30 August 1991

TOPIC -----

The printing on my ImageWriter II has become garbled garbage. It's missing the page breaks and prints onto other pages. This happens after about 6 or 7 pages have printed. I've tried cleaning the platen and replacing main circuit board.

DISCUSSION -----

This sounds like a handshake problem in communication between the computer and the printer. It could be caused by a number of glitches, among them a bad driver, bad cable, or printing software.

Try to recreate the problem using:

- a different computer with the same application and file
- a different printer
- a different printer cable

Copyright 1991, Apple Computer, Inc.

Tech Info Library Article Number:7817