



Tech Info Library

ImageWriter II: Dip Switch Settings for AppleTalk Card

Revised: 9/17/91
Security: Everyone

ImageWriter II: Dip Switch Settings for AppleTalk Card

=====

Article Created: 13 August 1991
Article Last Reviewed:
Article Last Updated:

TOPIC -----

How should the dip switches be set for an ImageWriter II with an AppleTalk card installed?

DISCUSSION -----

The only switch that needs to be changed is Switch Bank 2, Switch 4. Set it to the on/closed position.

Copyright 1991 Apple Computer, Inc.

Tech Info Library Article Number:8634