

## A/UX: Driver Needed for Ethernet Compatibility

Revised: 9/25/92 Security: Everyone

A/UX: Driver Needed for Ethernet Compatibility

\_\_\_\_\_\_

Article Created: 13 August 1991

Article Change History
----08/31/92 - REVIEWED

o For technical accuracy.

TOPIC -----

Does the correct EtherTalk driver installed into the Macintosh System folder make the Ethernet card compatible with A/UX? Does the A/UX kernel need to be modified for compatibility?

DISCUSSION -----

The Ethernet driver that you need to use with A/UX is called ae6. You add or remove this driver from A/UX via the newconfig(1M) command. You can check the man pages in A/UX for more information on this command.

Copyright 1991 Apple Computer, Inc.

Tech Info Library Article Number:8679