

A/UX: AppleTalk Can Use Enet Port Instead of LocalTalk (8/94)

Revised: 8/30/94 Security: Everyone

A/UX: AppleTalk Can Use Enet Port Instead of LocalTalk (8/94)

Article Created: 18 November 1991

Article Reviewed/Updated: 30 August 1994

TOPIC -----

How can I make AppleTalk use the Ethernet port instead of the LocalTalk port?

DISCUSSION -----

AppleTalk for A/UX is configured via the /etc/appletalkrc file. The interface entry defines if you use EtherTalk or LocalTalk. Follow these steps:

- 1) Use AppleTalk -d to bring the AppleTalk services down.
- 2) Change the appletalkrc file to reflect what you want.
- 3) Bring the services up with appletalk -u.
- 4) If you're in a Finder session, you must log out and log in again to see the changes.

Article Change History: 30 Aug 1994 - Reviewed

Support Information Services

Copyright 1991,1994 Apple Computer, Inc.

Tech Info Library Article Number: 9271