



Tech Info Library

AppleTalk Remote Access: AppleTalk Must Be Active (6/93)

Revised: 6/4/93
Security: Everyone

AppleTalk Remote Access: AppleTalk Must Be Active (6/93)

Article Created: 18 March 1992

Article Change History

06/07/93 - Added information about Always AppleTalk.

TOPIC -----

I installed AppleTalk Remote Access on my Macintosh PowerBook 170 and my Macintosh IIci (both are running System 7). When I try to go into Remote Access Setup, I get a message saying that AppleTalk Remote Access wasn't installed or that the extensions were turned off at startup.

I tried re-installing AppleTalk Remote Access from known-good disks on both systems, and I still get the same message.

DISCUSSION -----

This message appears when AppleTalk is not active.

To make AppleTalk active:

- 1) From the Apple menu, select Chooser.
- 2) In the Chooser window, click the AppleTalk Active button.
- 3) Restart your Macintosh.

You should now have access to AppleTalk Remote Access.

You can also use the Always AppleTalk software which is part of the PowerBook File Assistant collection of software. This allows a System 7.1 user to switch between AppleTalk being active and in active without restarting the computer.

Copyright 1992, 1993, Apple Computer, Inc.

Tech Info Library Article Number:10025