



Tech Info Library

StyleWriter: Manual-Feed Printing

Revised: 4/7/92
Security: Everyone

StyleWriter: Manual-Feed Printing

=====

Article Created: 26 March 1992
Article Last Reviewed:
Article Last Updated:

TOPIC -----

I'm having a problem printing manual-feed jobs on my StyleWriter printer, even though I'm using the standard manual-feed process:

- 1) Choose Print from the File menu.
- 2) Select the manual-feed option.
- 3) Click the "Print" button.
- 4) Wait for the dialog box saying to "Insert next sheet of paper."

When I insert the paper, I get an error, and the job doesn't print.

DISCUSSION -----

When using the manual-feed option with the StyleWriter, you need to deselect the printer before you insert the paper and then reselect it to print.

Follow these steps for printing manual-feed jobs on the StyleWriter:

- 1) Choose Print from the File menu.
- 2) Select the manual-feed option.
- 3) Click the "Print" button.
- 4) Wait for the dialog box saying to "Insert next sheet of paper."

..TIL10033-StyleWriter-Manual-Feed_Printing.pdf

- 5) Press the StyleWriter "Select" button to deselect the printer.
- 6) Insert the sheet (or envelope). The StyleWriter advances the paper about 1/2 inch.
- 7) Press the StyleWriter "Select" button again to reselect the printer.
- 8) Click "OK" in the dialog box to start the print job.

Copyright 1992 Apple Computer, Inc.

Tech Info Library Article Number:10033