



Tech Info Library

Apple Color Printer: Paper Loading Instructions

Revised: 1/4/93
Security: Everyone

Apple Color Printer: Paper Loading Instructions

=====

Article Created: 6 January 1993

TOPIC -----

This article tells you how to load the various types of paper into the Apple Color Printer.

DISCUSSION -----

The Apple Color Printer's input paper tray holds up to 100 sheets of 20-lb. paper. If you use heavier paper, fewer sheets fit in the input feeder. The Apple Color Printer can hold and automatically feed up to five envelopes. To avoid multiple feeding problems, insert transparencies one at a time.

NOTES:

- Acceptable Paper: 20-lb. cotton bond paper is recommended when using plain paper. The Apple Color Printer can feed 16- to 24-lb. paper.
- Don't mix print material.
- Don't load transparencies, envelopes, and paper in the feeder tray.

A head position lever helps the Apple Color Printer properly feed material through the print mechanism. Leave the head position lever in position 1 when using coated or medium weight plain paper. When printing images with heavy graphics, move the head position lever to position 2. Finally, when using thick paper, envelopes, or transparencies with the Apple Color Printer, move the head position lever to position 3.

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:11211