



Tech Info Library

LaserWriter Select 310: Grayscale Printing (2/93)

Revised: 2/8/93
Security: Everyone

LaserWriter Select 310: Grayscale Printing (2/93)

=====

Article Created: 9 February 1993

TOPIC -----

How do I print grayscale images on the LaserWriter Select 310?

DISCUSSION -----

The LaserWriter Select 310 prints dithered grayscale images using its PostScript Level I printer driver. The LaserWriter Select 310 with the PostScript driver can print up to 33 shades of gray.

To print documents in grayscale mode on the LaserWriter Select 310:

- 1) Open the Print dialog box and click on the Options button. This opens the Print Options dialog box.
- 2) Select the "Color/Grayscale" button under the "Print" setting.

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:11515