



# Tech Info Library

## AudioVision 14 Disp:Erratic Video SW Behavior (7/93)

Revised: 7/28/93  
Security: Everyone

AudioVision 14 Disp:Erratic Video SW Behavior (7/93)

=====

Article Created: 29 July 1993

TOPIC -----

This article discusses the erratic video slider control  
(software controlled) behavior.

DISCUSSION -----

Pressing the Volume key, Mute button, or Microphone-on button in  
combination with the Brightness or the Contrast button makes the  
software slider control (in the video control panel) behave erratically.

For example, if you press and hold the top of the Contrast button to  
adjust the slider control upward AND press the Mute button at the same  
time, the slider control continues upward toward the end, even after the  
buttons have been released.

Copyright 1993, Apple Computer, Inc

Tech Info Library Article Number:12713