

## AudioVision Display: Changing S-video Output Default 10/93

Revised: 10/20/93 Security: Everyone

AudioVision Display: Changing S-video Output Default 10/93

\_\_\_\_\_

Article Created: 20 October 1993

TOPIC -----

I connected the S-video output of a Macintosh 840AV to a Sharp projector unit. The menu bar was cut off at the top. I tried every adjustment on the Sharp, and could not get the menu bar back. I switched over to Composite out, and to the Sharp's composite in, and everything worked fine.

The Sharp unit checked out just fine with S-video coming from an S-video tape deck and nothing was missing at the top.

DISCUSSION -----

When the S-Video output is selected from the 840AV computer, the screen default setting is  $640 \times 480$ . This causes the display to overscan and that is why the menu bar is off the screen.

To remedy this situation, go into the control panel and double click on the monitor icon. Select the "option" button and a new window will appear. Select the 512 x 380 resolution and reboot the computer. The computer will now drive the display in the underscan mode and the entire screen will be visible.

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:13676