



Tech Info Library

LaserWriter Pro 810: Using the Printer's Control Panel (10/93)

Revised: 10/19/93
Security: Everyone

LaserWriter Pro 810: Using the Printer's Control Panel (10/93)

Article Created: 1 October 1993

TOPIC -----

This article describes the operator control panel key switches and their functions.

The printer's control panel lets you take the printer off line (to change settings) or on line (to print) and access menus for changing the printer's connection port, paper source, or resolution.

DISCUSSION -----

Use the keys on the control panel to display menu options and to change printer settings. An asterisk (*) appears in the display window next to any menu item currently selected.

KEY	FUNCTION
---	-----
ONLINE	Places the printer online or offline. Note, the printer must be offline for the other switches to be functional.
FORM FEED	Ejects the current page from the printer.
MENU	Displays the printer setup menu.
Up and Down arrows	Scrolls up or down through the setup menu.
RESET	Returns the selected menu item to the default value.
PRINT STATUS	Produces a report that supplements the information on the startup page; includes the total copy count, amount of memory on the printer, and the downloaded fonts.

ENTER Selects a menu item to display or select an option.

Copyright 1993, Apple Computer, Inc

Tech Info Library Article Number:13679