



# Tech Info Library

## Macintosh TV: If You Forget Your Password (11/93)

Revised: 11/1/93  
Security: Everyone

Macintosh TV: If You Forget Your Password (11/93)

=====

Article Created: 1 November 1993

TOPIC -----

If you create a password to lock out the TV mode of your Macintosh TV, and then forget the password, here's what to do.

DISCUSSION -----

- 1) Find the file named "TV Preferences" and drag it into the Trash.
- 2) Restart your Macintosh TV.
- 3) After the computer starts up, the TV Setup control panel will create a new "TV Preferences" file.
- 4) Set up the channels, name them, and create a new password if you wish.

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:13826