



Tech Info Library

LaserWriter Pro 810: Printing from Hypercard (2/94)

Revised: 2/7/94
Security: Everyone

LaserWriter Pro 810: Printing from Hypercard (2/94)

=====

Article Created: 7 February 1994

TOPIC -----

When I press Command-P to print a HyperCard stack or card to a LaserWriter Pro 810 (with a fax modem installed), the printer starts a fax transmission instead of printing the document.

How can I print a HyperCard document to a LaserWriter Pro 810?

DISCUSSION -----

This is a known problem which is documented in the ReadMe file on the LaserWriter Pro 810 Fax software disk.

To print HyperCard documents to a LaserWriter Pro 810 with a fax modem installed, press Shift-Command-P so that a Print Dialog Box is displayed before printing.

Note: If you attempt to print an document by selecting Print from the File menu, printing problems may occur.

Copyright 1994, Apple Computer, Inc.

Tech Info Library Article Number:14629