



Tech Info Library

LaserWriter 8.x: Configuring Paper Trays (3/94)

Revised: 3/14/94
Security: Everyone

LaserWriter 8.x: Configuring Paper Trays (3/94)

=====

Article Created: 14 March 1994

TOPIC -----

How can I configure the LaserWriter 8.x software so that it uses the 500 sheet tray?

DISCUSSION -----

Once the LaserWriter 8.x software is installed, it needs to be configured.

- 1) Open the Chooser
- 2) Select the LaserWriter 8.x driver
- 3) Select your printer
- 4) Click "Setup"
- 5) Click "Configure". If you don't see the "Configure" button, Click the "More Options" button
- 6) Select your cassette preference:
 - Not Installed
 - Installed
 - Installed and Preferred

After configuring the print driver, those paper tray options appear in the Print dialog.

Support Information Services

Copyright 1994, Apple Computer, Inc.

Tech Info Library Article Number:14869