



Tech Info Library

AppleShare: Disk is Unreadable (5/94)

Revised: 6/7/94
Security: Everyone

AppleShare: Disk is Unreadable (5/94)

=====

Article Created: 18 May 1994

TOPIC -----

When I mount a volume through AppleShare, I get the message that the disk is unreadable. What is going on?

DISCUSSION -----

It is very likely that there is an old version of DOS Mounter (prior to 3.0) in your System folder. Remove it, restart and try again. Contact Dayna for any updates to DOS Mounter.

Support Information Services

Copyright 1994, Apple Computer, Inc

Tech Info Library Article Number:15383