



Tech Info Library

At Ease: Eject Disk Doesn't Work-Can't Make Floppy Disks (8/95)

Revised: 8/14/95
Security: Everyone

At Ease: Eject Disk Doesn't Work-Can't Make Floppy Disks (8/95)

=====

Article Created: 1 July 1994
Article Reviewed/Updated: 14 August 1995

TOPIC -----

I am trying to make copies of a floppy disk, but it's not working. I have At Ease turned ON, but have gone to the Finder to make the disk.

DISCUSSION -----

While in At Ease, you cannot see diskette icons. If switched to Finder, you cannot create ghost icons with the 'Eject Disk' command in the Special menu.

Solution

Turn At Ease OFF and restart. You may then create disk copies using the ghost icon method (drop icon of destination disk on top of ghost icon of source disk).

Article Change History:

14 Aug 1995 - Corrected minor typo.
08 Aug 1995 - Added keyword; reviewed and reformatted article.

Support Information Services

Copyright 1994-95, Apple Computer, Inc.

Tech Info Library Article Number:15735