



Tech Info Library

LaserWriter Select Printers: Fuser Temperature (10/94)

Revised: 10/3/94
Security: Everyone

LaserWriter Select Printers: Fuser Temperature (10/94)

=====

Article Created: 3 October 1994

TOPIC -----

What is the fuser temperature of the LaserWriter Select 300/310/360? I am trying to use some special labels that may be damaged if the temperature exceeds 410 degrees.

DISCUSSION -----

The fusing temperatures for the LaserWriter Select printers are as follows:

LaserWriter Select 300/310

Paper Size -----	Fusing Temperature (Max) -----
A4, Letter, Legal	320°F (160°C)
Post Card, COM-10, Monarch, C5, DL	331°F (166°C)

LaserWriter Select 360

Paper Size -----	Fusing Temperature (Max) -----
A4, Letter, Legal	331°F (166°C)
Post Card, COM-10, Monarch, C5, DL	361°F (183°C)

Support Information Services

Copyright 1994, Apple Computer, Inc

Tech Info Library Article Number:16430