



# Tech Info Library

## LaserWriter 16/600 PS: BootP Requires Same Subnet (12/94)

Revised: 12/13/94  
Security: Everyone

LaserWriter 16/600 PS: BootP Requires Same Subnet (12/94)

=====

Article Created: 13 December 1994

DISCUSSION -----

The LaserWriter 16/600 manual states that you must use the bootp software from a computer on the same subnet as the printer. I am using a Wellfleet's router that has the ability to interpret bootp communications, so does this negate the manual's statement or is the same subnet a hard and fast requirement?

DISCUSSION -----

You must follow the manual, and use a computer on the same subnet as the printer. This must be done because the Wellfleet router listens on port 67 for BootP requests, and the Laserwriter 16/600 PS printer sends out a BootP request using port 68. This is a broadcast message, so the printer sends out a broadcast message to address 255.255.255.255, this is also called a limited broadcast address, any datagram which is destined for the limited broadcast address is NEVER forwarded by a router under any circumstance. It only occurs on a local physical cable.

Support Information Services

Copyright 1994, Apple Computer, Inc

Tech Info Library Article Number:16886