Tech Info Library

LaserWriter: LaserWriter Fax Tune-Up ReadMe (2/95)

```
Revised:        2/9/95
Security:       Everyone
```

LaserWriter: LaserWriter Fax Tune-Up ReadMe (2/95)

===

Article Created: 9 February 1995

TOPIC ---

This article contains the LaserWriter Fax Tune-Up ReadMe file.

DISCUSSION --

Using LaserWriter Fax Tune-Up

WHY
The fax tune-up program prevents certain problems when you print out oversize
faxes on your LaserWriter printer.

• If you receive banner-size or legal-size faxes, your printer will reduce the
fax to fit the paper size that's in the largest-size paper tray you have
installed (letter, A4, or legal).

• If you receive letter-size faxes with no margins, your printer will reduce the
fax to fit letter-size paper with margins.

HOW
1. Open the Chooser and make sure that the printer you use for your faxes is
selected.

2. Open the fax tune-up program.

IMPORTANT
If you have restarted your printer, or turned it off and then on again, you have
to open the fax tune-up program AGAIN before using your printer to print out
oversize faxes. The printer keeps the instructions it receives from the fax
tune-up program in its memory, and it loses those instructions when it is turned
off or restarted.

Support Information Services

Tech Info Library Article Number:17154