



Tech Info Library

Apple Media Conference: Using TCP/IP w/ PowerTalk Installed 8/95

Revised: 8/15/95
Security: Everyone

Apple Media Conference: Using TCP/IP w/ PowerTalk Installed 8/95

=====

Article Created: 10 July 1995
Article Reviewed/Updated: 15 August 1995

TOPIC -----

I cannot use TCP/IP addresses in Apple Media Conference with PowerTalk Collaboration Services activated. I have to open the PowerTalk Setup control panel deactivate Collaboration Services, then restart my Macintosh. Is there any way to use both PowerTalk and TCP/IP from within Apple Media Conference?

DISCUSSION -----

Although you can select TCP/IP as the default for watching or broadcasting, this preference is not used when PowerTalk Collaboration Services is activated. With PowerTalk active, the PowerTalk dialog always appears when trying to watch or broadcast a QuickTime Conference. To enter TCP/IP addresses instead of using the PowerTalk dialog, hold down the OPTION key when choosing Broadcast or Watch from the File menu.

Article Change History:
15 Aug 1995 - Changed access information.

Support Information Services

Copyright 1995, Apple Computer, Inc.

Tech Info Library Article Number:18112