



Tech Info Library

LaserWriter 16/600 PS: Resetting Using UNIX (8/95)

Revised: 8/15/95
Security: Everyone

LaserWriter 16/600 PS: Resetting Using UNIX (8/95)

=====

Article Created: 14 August 1995
Article Reviewed/Updated: 15 August 1995

TOPIC -----

This article describes how to change subnet mask of the LaserWriter 16/600 from a UNIX workstation.

DISCUSSION -----

Follow these steps to reset the LaserWriter 16/600 PS to its default values using UNIX:

Step 1

Remove the printer and a UNIX workstation from the network.

Step 2

Connect the UNIX workstation directly to the printer

Step 3

Terminate both ends of the connection between the workstation and the printer.

Step 4

Set the subnet mask on the workstation to be the same as the printer.

Step 5

Set the default gateway on the workstation to the IP address of the printer.

Step 6

Logon onto the printer as normal using TELNET.

Step 7

Select the option to reset to factory specs.

Step 8

Set the work station back to the proper address masking

Step 9

Reconnect all hardware to the network.

Article Change History:

15 Aug 1995 - Updated for technical accuracy and changed title.

Support Information Services

Copyright 1995, Apple Computer, Inc.

Tech Info Library Article Number:18364