..TIL58217-Apple_Studio_Display_21Apple_Studio_Display_17_Tripod_Stand_Safety_Tips.pd

Apple Service - Troubleshoot and Repair

Tech Info Library

Home - CD Index - Feedback

Apple Spec DB - Hard Drives Matrix - Memory Guide -

Parts DB - Service Manuals - Software Troubleshooting

Service Programs Manual Index - U.S. - Canada

CompTIA Codes - Ordering Parts FAQ - Product Service

Matrix - REAs - Service Excellence

TITLE

Apple Studio Display 21/Apple Studio Display 17: Tripod Stand Safety Tips

Article ID: 58217 Created: Modified: 1/13/00

TOPIC

This article provides specific safety tips relating to the new tripod stand used on the Apple Studio Display 21" and Apple Studio Display 17" displays.

DISCUSSION

- · Lift the display by the indentations on the under-sides near the front of the display. Never lift the display by the tripod stand.
- Likewise, do not adjust the position of the monitor by pulling the stand legs. The tripod stand is subject to damage if mishandled.
- When placing the monitor on a table surface, ensure that all three legs on the tripod stand contact a solid surface. If one of the legs is too close to the table edge, the weight of the monitor could cause the display to fall off the edge.

Note: The Viewable Image Size of the Apple Studio Display 21" is 19.8 inches, the Apple Studio Display 17" has a Viewable Image Size of 16.0 inches.

EXTENDED Information - Apple Internal Use - Service Providers and Support Professional

Document Information

Product Area: Monitors-Displays Macintosh Displays Category:

Sub Category: Studio Display 17; Studio Display 21

APPLE NEED-TO-KNOW CONFIDENTIAL: Do NOT forward, copy, or otherwise replicate or disseminate verbally, electronically, or in hardcopy (except to those individuals within your organization who have a legitimate business need to know the information, and who have agreed in writing, to keep it confidential), unless Apple has given prior written authorization.

Copyright © 1999-2000, Apple Computer, Inc.