Apple Service - Troubleshoot and Repair

Tech Info Library

TITLE

iMac (Slot Loading): Installing AirPort Card

Article ID: 58537
Created: 12/1/99
Modified: 1/24/00

TOPIC

This article provides instructions for installing the AirPort Card into an iMac (Slot Loading) computer. Similar instructions, with graphics, are included with the AirPort Card.

DISCUSSION

1. Before installing, shut down the computer, unplug all cables, except the power cord, and place the computer face down on a soft cloth.
2. Unlock the access door using a coin, then open the door.
3. Touch the metal shield inside the recessed latch area to discharge static electricity, then unplug the power cord from the computer. Don't walk around the room until you've finished installing the AirPort Card.
4. Detach the antenna from the left rail guide on the upper AirPort Card slot and remove the protective cap. Then connect the antenna to the AirPort Card.
5. Align the edges of the AirPort Card with the guides on the slot and insert the AirPort Card sideways into the slot.
6. Close the access door and use a coin to lock it. Reconnect all cables and cords, then press the Power button on the computer. Never turn your computer on unless all of its internal and extra parts are in place.
   Instructions for using the AirPort software are in Mac Help, available in the Help menu.

EXTENDED Information - Apple Internal Use - Service Providers and Support Professional