



Tech Info Library

Centris 660AV & Quadra 840AV: Speech Recognition Settings (8/93)

Revised: 8/19/93
Security: Everyone

Centris 660AV & Quadra 840AV: Speech Recognition Settings (8/93)

Article Created: 10 August 1993
Article Reviewed/Updated: 19 August 1993

TOPIC -----

What settings must I check to enable speech recognition on the Macintosh Centris 660AV and Quadra 840AV?

DISCUSSION -----

For speech recognition to work, the Sound control panel settings must be:

- Sample rate: 24.000 kHz (This is the preset rate)

To set the sample rate:

- 1) Open the Sound control panel
- 2) Choose Sound Out from the pop-up menu
- 3) Choose 24.000 kHz from the Rate pop-up menu

- Input Source: Microphone (This is the default setting.)

- 1) Open the Sound control panel.
- 2) Choose Sound In from the pop-up menu.
- 3) Click on the Options button.
- 4) Click the radio button marked Microphone.
- 5) Click the OK button to return to the Sound control panel.

- Playthrough: off (This is the default setting.)

- 1) Open the Sound control panel.
- 2) Choose Sound In from the pop-up menu.
- 3) Click on the Options button.
- 4) Make sure the checkbox marked Playthrough is unchecked.
- 5) Click the OK button to return to the Sound control panel.

Article Change History:

19 August 1993 - Added Microphone as input sound source information.

Copyright 1993, Apple Computer, Inc.

Tech Info Library Article Number:12903