



Tech Info Library

Apple CD-ROM Software 5.3.2 Read Me (3/97)

Revised: 3/4/97
Security: Everyone

Apple CD-ROM Software 5.3.2 Read Me (3/97)

=====

Article Created: 4 March 1997

TOPIC -----

This article contains the ReadMe document included with Apple CD-ROM software version 5.3.2.

DISCUSSION -----

About Apple CD-ROM Version 5.3.2

This file includes important information about Apple CD-ROM version 5.3.2, software that lets you use an Apple CD-ROM drive with your Macintosh computer. You need system software version 7.1 or later of the Macintosh Operating System (Mac OS) to use this software. Because this information is not included in the documentation accompanying the product, you may want to print it. To do so, choose Print from the File menu.

Installation Instructions

IMPORTANT The full instructions below assume you have an Apple CD-ROM installation disk. If, instead, you're downloading the Apple CD-ROM software from an online service, follow step 1, below. Next, copy the software onto your hard disk and double-click the Installer icon to start the Installer. Then follow steps 5 through 9.

To install this extension, follow these steps:

1. While holding down the Shift key, choose Restart from the Special menu and continue to hold the key down until you see a message. When a message on the screen tells you that the extensions are off, release the Shift key.

When you restart the Macintosh after you install Apple CD-ROM version 5.3.2, the extensions will turn on again.

2. Make sure the Apple CD-ROM installation disk is locked.

3. Insert the Apple CD-ROM installation disk into a disk drive.

If you can't see the Installer icon, double-click the disk icon to open it.

4. To start the Installer program, double-click its icon.

5. In the Welcome dialog box that appears, click Continue.

After a moment, the Install dialog box appears.

IMPORTANT When you started the Installer, it checked to make sure you have what you need to use the software. If you're missing anything, you'll now see a message that tells you what you need. You won't be able to install the software until you correct the problem. If a dialog box says you don't have the correct system software, you can purchase a new version of system software from an Apple-authorized dealer.

6. Make sure the disk named in the Destination Disk box is the one on which you want to install the software. If it's not, click Switch Disk until the correct disk name appears.

7. Click the Install button.

The Installer takes a few moments to calculate what needs to be done and then begins to install files.

8. Follow the instructions on the screen until the installation is complete.

9. When you see a message reporting that installation was successful, click Restart to restart your Macintosh.

The Apple CD-ROM software is now installed on the hard disk.

Improvements to the Software

Version 5.3.2

For CD Extra discs, the Apple CD-ROM software mounts both the HFS and ISO partitions (if present), allowing AppleCD Player to locate and use the CD Extra data regardless of what partition it is on.

Version 5.3.1

Previously you may have received occasional error messages when scanning (fast-forwarding) between tracks in shuffle and program modes. This problem has been corrected in version 5.3.1.

Version 5.3

The Apple CD-ROM software supports all current Apple CD-ROM drives.

Version 5.2

The Apple CD-ROM software now supports ATAPI CD-ROM drives, such as those used in the Macintosh PowerBook 1400.

Previously system errors could occur when a shared CD-ROM drive was accessed by a client computer. This has been corrected in version 5.2.

Previously the CD-ROM drive may have gone into sleep mode while playing an audio CD. This problem has been corrected in version 5.2.

Version 5.1.7

The Apple CD-ROM software now works with 6x-speed CD-ROM drives.

Version 5.1.6

The Apple CD-ROM software now works with Apple PC Compatibility Cards for PCI-based Macintosh computers.

Version 5.1.5

If you have an Apple CD-600 drive and were using Apple CD-ROM version 5.1, you may have had intermittent problems playing the Peter and the Wolf CD. In version 5.1.5, this problem has been corrected.

Previously a Photo CD with more than 30 sessions would not start up properly. Now a Photo CD of up to 50 sessions (the theoretical maximum number of sessions on a Photo CD) will start properly.

(c) 1997 Apple Computer, Inc. All rights reserved. Apple, the Apple logo, Mac, Macintosh, and PowerBook are trademarks of Apple Computer, Inc., registered in the U.S. and other countries. AppleCD is a trademark of Apple Computer, Inc.

Updated January 20, 1997

Copyright 1997, Apple Computer, Inc.

Tech Info Library Article Number:21064