



Tech Info Library

AppleShare for Windows: Install Issue w/Ethernet Pro NIC (7/95)

Revised: 7/20/95
Security: Everyone

AppleShare for Windows: Install Issue w/Ethernet Pro NIC (7/95)

=====

Article Created: 10 July 1995
Article Reviewed/Updated: 20 July 1995

TOPIC -----

I have an Ethernet Pro Network Interface Card and am trying to run Appleshare for Windows. Whenever I launch Appleshare for Windows, I get the message, "AppleTalk Driver was not loaded. Please reinstall AppleShare".

DISCUSSION -----

If the workstation has an Intel Ethernet Pro Network Interface card installed when the Appleshare for Windows installation takes place, the Installer omits a necessary parameter for protocol AARP.

You must edit the NET.CFG file and change the line -
 PROTOCOL AARP ETHERNET_SNAP
to-
 PROTOCOL AARP 80F3 ETHERNET_SNAP

Article Change History:
20 Jul 1995 - Corrected format problem.

Support Information Services

Copyright 1995, Apple Computer, Inc.

Tech Info Library Article Number:18120