

AppleWorks: RamWorks Card Needs Larger Memory Capacity (9/95)

This technical note describes the procedure to correctly interface the above products to allow larger memory capacities with the AppleWorks application.

What You Need

Before you begin, be sure you have the following:

- 1. ProDOS users disk.
- 2. Desktop Expander disk from Applied Engineering.
- 3. AppleWorks startup and program disks.
- 4. Catalyst disk.

Procedure

Step 1

Boot the Desktop Expander disk and follow the instructions. This will modify your AppleWorks disk so that it can use the additional memory of the Ramworks board IIe card.

Step 2

Create a subdirectory on your hard disk using Apple's ProDOS Users disk called

"/PROFILE/AW"

```
Step 3
Copy all of the files from the AppleWorks Startup and Program disks to the
subdirectory you just created.
Step 4
Once the files have been copied, start up your Catalyst disk and select the
Catalyst Editor.
Step 5
Move the cursor to the point where you wish to add your AppleWorks program and
press"A".
Step 6
Type "APPLEWORKS" for the program name.
Step 7
____
Type "AW/APLWORKS.SYSTEM" for the interpreter pathname.
Step 8
Type "AW" for the initial prefix.
Step 9
Press RETURN for the program path.
Step 10
You will be asked if all items are correct. Answer "Y" and press ESCAPE to exit
to the main menu.
Step 11
Enter "U" to update the INTERPS2E file.
Step 12
Exit to the Catalyst main menu by entering "Q".
When you select the AppleWorks program from the main menu you will notice that
you now have 101K available for data storage.
NOTE: Apple Computer Inc. is not responsible for the contents of this article.
Article Change History:
19 Sep 1995 - Reformatted to meet current standards.
```

..TIL01526-AppleWorks-RamWorks_Card_Needs_Larger_Memory_Capacity_9-95_(TA31636).pd

Support Information Services

Quark Tech Support

Tech Info Library Article Number:1526