



Tech Info Library

Apple IIe Card: Which Drives are Supported

Revised: 6/10/92
Security: Everyone

Apple IIe Card: Which Drives are Supported

=====

Article Created: 13 August 1991
Article Last Reviewed: 3 June 1992
Article Last Updated: 3 June 1992

TOPIC -----

- 1) What disk drives does the Apple IIe Card support?
- 2) Why hook up a UniDisk 3.5-inch to the Apple IIe Card?
- 3) How do I eject the internal 3.5-inch disk?
- 4) If I connect a compatible Apple 5.25 Drive to this Macintosh LC, can I run regular Apple IIe software?

DISCUSSION -----

- 1) The Apple IIe Card supports the following drives:
 - The two Internal Macintosh LC SuperDrive disk drives
 - One UniDisk 3.5-inch (part number A2M2053, white).
 - Two Apple 5.25-inch Disk Drive (part number A9M0107, platinum) connected to the drive cable or UniDisk 3.5. Note: If you hook up a UniDisk 3.5-inch and Apple 5.25-inch, the UniDisk 3.5-inch goes first.

The Apple IIe Card does NOT support:

- The Apple 3.5-inch
- UniDisk (beige 5.25-inch)
- DuoDisk
- Disk II

The older 5.25-inch drives use -12 volts, which the Macintosh LC does not support.

2) Some copy-protected applications require a UniDisk 3.5-inch as part of the configuration, or they won't work correctly. Nor do they work on the SuperDrive inside the Macintosh LC.

3) To eject a disk from an internal 3.5-inch disk:

- Press Command-Shift-1
- Enter the Option Panel (Command-Control-Esc) and press the Disk Eject button.

4) Yes. In Apple IIe mode, the Macintosh LC will function exactly as an Apple IIe.

Copyright 1991, 1992 Apple Computer, Inc.

Tech Info Library Article Number:8807